



Customer Service
(800) 247-7668

FLANGE WALL PADDING

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ Read all instructions before proceeding.

Warning!

Per ASTM F2440-04 The bottom of all wall padding should be mounted no more that 4" from the floor

1. Once you have selected the appropriate mounting hardware for the wall type you are covering pre-drill clearance holes for the mounting hardware two places on the top and bottom flange in each wall pad.
2. Position pads on the wall making sure the bottom of the pad is no more than 4" from the floor and level. If needed mark the wall through the pre-drilled holes, remove the pad and drill into wall for anchors or clearance holes for the padding mounting hardware.
3. It is common for the wall that the padding is being mounted to not be flat or in the exact same plane. This can cause unsightly wrinkling of the vinyl. Shimming the center of the padding as needed will help offset wall irregularities, stretch the vinyl and improve the finished appearance.
4. It is recommended to use a washer under the head of the screw/bolt used to attach wall pad.

