

— Instruction Manual —
BA776DB, BA778DB AND BA781DB



Back to Back Supplemental Assembly Instructions

Customer Service
(800) 247-7668

Note:

These instructions address back to back extension arm installation only. You will need to follow the instructions provided in the hardware box for pole, backboard, rim and brace installation .

1. Once pole is set and the concrete is cured install extension arms at the height described in the original assembly instructions using the 1/2" Hex Bolts provided with this instruction and the 1/2" Flat Washers, 1/2" Lock Washers and 1/2" Hex Nuts in the original hardware box.
2. The U-bolts provided in the original hardware box are used for single extension arm assembly. They can be discarded when you install extension arms back to back. If you choose to position arms at different heights you will need to follow the original instructions for correct installation.
3. Once extension arms are installed refer to the original assembly instructions to complete installation.

Warning!

All BA781DB systems require the Extension Brace Q. Failure to install Extension Brace Q will result in system failure and/or injury. Refer to the BA781 instructions to attach the Extension Brace Q.

